



ENGENIUS ROUTER CONFIGURATION

1. Power up the Router
2. Connect the Router to your Laptop via an Ethernet cable
3. Disable the Wireless card on your laptop and open up a browser
4. Type in the browser 192.168.0.1
5. Select Expert mode to display the Login Page
6. Type in the default password : admin and click Login
7. Click on System
8. Click on Operation Mode and Select Client Bridge in the drop down menu and click Apply
9. Wait for the router to configure to Client Bridge Mode
10. Click on Wireless
11. Click on Basic
12. Click on Site Survey and click on Apply
13. The router will present a list of all the networks available in the area in a table
14. Select the Network you want to connect to and scroll down the page to click on Add to AP Profile
15. If a password is required you'll be presented with a blank window named Pre-shared Key; Type in the password and click Save
16. Click on Close
17. You'll now be presented with an AP Profile Table that shows you the network you selected and the option to select it again. Select it again by checking the last box and click on Connect.
18. The Router should connect to the network

19. If the router says connection status failed, Reset the router by pressing on the WPS button (the only Button on top of the device) for 15 seconds and restart the process. If it fails again contact Ali.
20. If the connection status is successful open a browser on your laptop and browse a website; if successful, disconnect the Ethernet cable from the laptop, connect it to the Media Player and restart the Media Player. If it picks up an IP, make sure you check the maps and send an email or text message.